Verbindungskabel

- Verbindungskabel zwischen externer Steuerung und Kontaktflächen oder zwischen Hutschienen-Netzteil und Kontaktflächen – NZ80063A
- Verbindungskabel zwischen Netzteil und Kontaktflächen NZ80219
- Verbindungskabel zwischen Netzteil und Kontaktflächen mit Steuerleitung für externe Zutrittskontrollen oder Gegensprechanlagen – NZ80118B
- Verbindungskabel zwischen Netzteil und Steuerung mit 12 V DC-Abzweigung für externe Zutrittskontrollen oder sonstige Verbraucher – NZ80172
- Verbindungskabel zwischen Steuerung und Hutschienen-Netzteil – NZ80267

Connecting cables

- Connecting cable for linking the external control unit and the contact surfaces or the rail-mounted mains adapter and the contact surfaces – NZ80063A
- Connecting cable for linking the mains adapter and the contact surfaces – NZ80219
- Connecting cable for linking the mains adapter and the contact surfaces, including control cable for external access control or intercom systems – NZ80118B
- Connecting cable for linking the mains adapter and the control unit, including 12 V DC branch cable for external access control systems or other consumers – NZ80172
- Connecting cable for linking the control unit and the mains adapter for top rail mounting – NZ80267



